

## ASSEMBLY INSTRUCTIONS FOR AQUA MAT TROLLEY

1. It is very important to follow the steps according to this instruction otherwise assembly may lead to damaging the product. Warranty is applicable only for correctly assembled trolleys.
2. Put 8pcs of vertical tubes **250mm** on the bottom part A of the trolley. IMPORTANT!!! Please make sure to use only **250mm** parts for this step of assembly. (Pic. 1)
3. Insert part B into **250mm** tubes. Please make sure the part B is not turned upside down! It is recommended to insert part B smoothly and evenly into all tubes at the same time. (Pic. 1)
4. Put 6 pcs of tubes **250mm** and 2 pcs **205mm** (marked as RED colour in the drawing) on the part B of the trolley. IMPORTANT!!! Please make sure 2pcs of **205mm** tubes are inserted in the correct places as shown in the images. (Pic. 1)
5. Insert part B into vertical tubes. (Pic. 2)
6. Put 6 pcs of tubes **250mm** and 2 pcs HR6 **205mm** on the part B of the trolley. (Pic. 2)
7. Insert part B into 250mm vertical tubes. (Pic. 2)
8. Put 6 pcs of vertical tubes **250mm** and 2 pcs HR6 **205mm** on the part B of the trolley. (Pic. 2)
9. Insert part C into tubes. Please make sure the part C is not turned upside down! (Pic. 3)
10. Part C has a removable stop bar (PART D). Please use it after storing aqua mats into your trolley. (Pic. 3)
11. Your trolley is ready to use!



